



COOKTOP PARTS

For Models: GY397LXUQ0, GY397LXUB0, GY397LXUT0, GY397LXUS0


(White)

(Black)

(Biscuit)

(S.Steel)

30" SLIDE-IN
ELECTRIC RANGE




Illus. No.	Part No.	DESCRIPTION
1	W10203741	Literature Parts Use & Care Guide
	W10203740	Installation Instructions
2		Cooktop
	W10170209	White
	W10170210	Black
	W10170211	Biscuit
	W10170212	S.Steel
3	12001676	Kit, Hardware
4	74008897	Element (RF,LR)
5	74008568	Element (LF,RR)
6	74005759	Tube, Vent Upper
7	Y700502	Screw
8	74003072	Support,Element
9	74011799	Light, Indicator

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GY397LXUQ0, GY397LXUB0, GY397LXUT0, GY397LXUS0

(White) (Black) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	74005769	Lens	6		Panel,Control(lwr)	9		Knob (RF,LR)
2		Panel, Control		W10185606	Black		7737P417-60	Black
	7720P535-60	Black		W10185607	White		7737P418-60	White
	7720P536-60	White		W10185609	Biscuit		7737P419-60	Biscuit
	7720P537-60	Biscuit	7		Knob (LF,RR)	10	W10203695	Support, Control Panel
	W10182766	S.Steel		7737P414-60	Black			
3	7101P309-60	Screw		7737P415-60	White	11	Y700502	Screw
4		Switch, Infinte		7737P416-60	Biscuit	12	74004153	Light, Indicator
	74010824	8" (RF,LR)	8		Switch, Membrane	13	W10187161	Overlay (S.Steel Mdl Only)
	7403P238-60	6" (LF,RR)		W10177225	Black			
5	W10203701	Control		W10177224	White			
				W10177226	Biscuit			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS


For Models: GY397LXUQ0, GY397LXUB0, GY397LXUT0, GY397LXUS0

(White)

(Black)

(Biscuit)

(S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: GY397LXUQ0, GY397LXUB0, GY397LXUT0, GY397LXUS0

(White)

(Black)

(Biscuit)

(S.Steel)

Illus. No.	Part No.	DESCRIPTION
1		Panel, Shield
	74010821	Left
	74010822	Right
2	74010819	Latch Assembly
3	74010807	Cover, Front
4	74011465	Main Back
5	W10203736	Cover, Main Wire
6	74010815	Extension, Back
7	Y700502	Screw
8	74006364	Insulator, Cord
9	74003976	Screw
11	74010823	Fan, Cooling
12	74010812	Support,Oven Btm
13	7101P124-60	Screw
14	74003040	Element, Broil
15	74004943	Sensor, Oven
16	W10165722	Tube, Vent Lower
17	74010886	Tube, Vent Upper

Illus. No.	Part No.	DESCRIPTION
18	71001394	Screw (4)
19	74010817	Holder, Vent Tube
20	74008597	Smoke Eliminator
21	W10165724	Plate, Smoke Elm.
22	74010885	Light Assembly
23	74004180	Bracket,Pwr Supply
24	7407P103-60	Bulb, Oven
25		Trim, Side
	74010832	White (2)
	74010831	Black (2)
26	71001394	Screw
27	74010883	Element, Bake
28	74010884	Support, Oven Rear
29	71001394	Screw
30	74011142	Hinge (2)
31	4159193	Screw, Hinge (4)
32	74010818	Switch, Hi-Limit
33	74005564	Bracket,Anti-Tip
34	74010820	Extention, Shield

Illus. No.	Part No.	DESCRIPTION
35	74003386	Support, Element
36	74010805	Leg, Leveling
37	74010899	Pedestal, Bottom
38	74010882	Pedestal, Front
39	74007129	Support
40	74003565	Runner, Drawer (2)
41	74004078	Roller, Drawer (2)
42	74005231	Shaft, Roller (2)
43	74005230	Nut, Lock (2)
44	74006522	Retainer, Bottom

INSULATION

74010987	Insulation, Wrap
W10165725	Insulation, Back
74011207	Insulation, Oven Bottom

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS


For Models: GY397LXUQ0, GY397LXUB0, GY397LXUT0, GY397LXUS0

(White)

(Black)

(Biscuit)

(S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	W10165729	Trim, Door Top
	W10165726	Black
	W10177497	White
	W10168887	Biscuit
	W10168887	S.Steel
2	W10163951	Screw, Handle (2)
3	74011457	Baffel, Retainer
4	74001530	Screw 8AB 1/2
5	74003645	Glass, Inner (2)
6	74005546	Spacer, Rubber
7	74001574	Nut, Snap (4)
8	74011456	Lining, Door
9	74011458	Bracket, Glass (2)
10	74003647	Insulation, Door
11	Y700502	Screw
12		Bracket, Handle
	74009699	Left
	74009698	Right
13	74004224	Tape, White

Illus. No.	Part No.	DESCRIPTION
14		Trim, Door Side
	74009693	Black, Left
	74009695	White, Left
	74009697	Biscuit, Left
	74009692	Black, Right
	74009694	White, Right
	74009696	Biscuit, Right
15		Tape, Double Sided
	74009014	White
	74009025	Black
16		Trim, Door Bottom
	74009687	White
	74009686	Black
	74009688	Biscuit
17		Screw, Trim
	74009540	White
	74009539	Black
	74009541	Biscuit
	74009268	S.Steel

Illus. No.	Part No.	DESCRIPTION
18	W10162384	Seal, Door
19		Glass, Door
	W10170228	White
	W10170229	Black
	W10170230	Biscuit
	W10170231	S.Steel
		(Order Items 13 & 21 When Replacing Door Glass)
20		Handle, Door
	W10118430	White
	W10118431	Black
	W10118432	Biscuit
	W10144883	S.Steel
21	74003664	Tape, Foil
22	8303810	Nameplate, Logo
23	74010267	Spacer, Rubber

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRAWER AND RACK PARTS


For Models: GY397LXUQ0, GY397LXUB0, GY397LXUT0, GY397LXUS0

(White)

(Black)

(Biscuit)

(S.Steel)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	74001813	Rack, Oven (2)
2	74008333	Drawer, Storage
3	74004310	Screw, Panel
4	74010896	Bracket, Drawer

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

5		Panel, Drawer
	74003407	White
	74003701	Black
	74004966	Biscuit
	W10160943	S.Steel
6		Screw, Panel
	74009540	White
	74009539	Black
	74009541	Biscuit
	74009538	S.Steel

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

7	74005230	Nut, Lock
8	2404F030-51	Lining, Drawer
9	74005546	Spacer, Rubber
10	74004078	Roller, Drawer (2)
11	74005231	Shaft, Roller (2)
12	7103P082-60	Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: GY397LXUQ0, GY397LXUB0, GY397LXUT0, GY397LXUS0

(White)

(Black)

(Biscuit)

(S.Steel)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Parts Not Illustrated and
Optional Parts (Not Included)

SPLICING WIRES--25FT.

LENGTH

242828	Wire, Black
	12 Ga. 150° c
242821	Wire, Blue
	14 Ga. 150°c
242822	Wire, Brown
	14 Ga. 150°c
242830	Wire, Brown
	14 Ga. 200°c
242823	Wire, Green
	14 Ga. 150°c
242824	Wire, Orange
	14 Ga. 150°c
242825	Wire, Red
	14 Ga. 150°c
242831	Wire, Red
	14 Ga. 200°c
242827	Wire, Yellow
	14 Ga. 150°c

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

REFINISHING MATERIAL

799832	Kit, Porcelain
	Repair (White)
242756	Touch-Up
	Self-Clean(1/2 Pt)
261582	Grease

INSULATION

261514	Insulation,
	Fiberglass (1-1/2"
	x 24" x 120")
240132	Insulation,
	Fiberglass (2-1/2"
	x 22" x 120")

PAINT, TOUCH-UP (1/2oz.)

72017	White
4392899	Biscuit
511873	White Porcelain
	(2 Oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit(Uncut)

ACCESSORY PARTS

241430	Foil, Aluminum
	Oven (18" x 25')
3191048	Cleaner, Glass

WIRING HARNESS PARTS

74010849	Harness, Sensor
5171P974-60	Harness, Top
74011549	U3, Harness (RT)
74011572	Coil,Harness (Lt)
5171P976-60	Harness, Main
74006811	Clip, Wire

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST